



## WIIC Region Code Settings Instruction Manual

Enabling "auto region" with EJECT Button Programming


### General Instructions:

1. Attach the 5 welding points (G, V, A, B, C) to the console, as shown by the diagram. This completes the basic installation step.
2. As of this step, without modifying any region codes, the Japanese console can read Japanese Backups, U.S. machines can read U.S. Backups, PAL consoles can read PAL Backups.
3. Follow these steps to read all region files.
4. All region access and WIICOS (upgradeable interface) settings need to be set once.
5. When completing the following steps, make sure there is no DVD in the Disc Tray!

Note: WI-IC Basic Function (version 0.2) can only do "auto region" for Wii Backups, GC "auto region" requires a firmware update being applied.

This also serves as "safety" measure. So wrong region settings will keep the GC DVD's all readable, so it is possible to use Update DVD or SDLOAD Boot DVD to perform firmware update.

Note: without region setting it is also possible to use other region DVD's but those should be patched before burning. The Auto Region allows non-patched DVD's to be used.





## Japanese Console Instructions

Enable JP console

(Caution: Each step will be confirmed by the flashing WIIC LED light, make sure the light flashes completely before proceeding to the next step)

---

POWER ON

REMOVE DVD FROM DVD TRAY

**There should be no DVD in Tray during the all sequence!**

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

POWER OFF

POWER ON

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 2

EJECT, Wait Disc Tray not moving, LED will Flash 1, 3

EJECT, Wait Disc Tray not moving, LED will Flash 1, 4, 1, 1

POWER OFF

Now param1 has been set, this enable JPN Region Patching



## US Console Instructions

Enable US console

=====

POWER ON

REMOVE DVD FROM DVD TRAY

**There should be no DVD in Tray during the all sequence!**

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 2

POWER OFF

POWER ON

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 2

EJECT, Wait Disc Tray not moving, LED will Flash 1, 3

EJECT, Wait Disc Tray not moving, LED will Flash 1, 4, 1, 2

POWER OFF

Now param2 has been set, this enable US Region Patching



## EU Console Instructions

Enable EU Console

=====

POWER ON

REMOVE DVD FROM DVD TRAY

**There should be no DVD in Tray during the all sequence!**

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 2

EJECT, Wait Disc Tray not moving, LED will Flash 1, 3

EJECT, Wait Disc Tray not moving, LED will Flash 1, 4, 1, 1

POWER OFF

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 2

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 2

EJECT, Wait Disc Tray not moving, LED will Flash 1, 3

EJECT, Wait Disc Tray not moving, LED will Flash 1, 4,1, 2

POWER OFF

Now param1 and param2 have been set, this enable PAL Region Patching



## Disabling Auto Region

=====

POWER ON

REMOVE DVD FROM DVD TRAY

**There should be no DVD in Tray during the all sequence!**

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 2

EJECT, Wait Disc Tray not moving, LED will Flash 1, 3

EJECT, Wait Disc Tray not moving, LED will Flash 1, 4, 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 5, 1, 1

POWER OFF

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 2

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 2

EJECT, Wait Disc Tray not moving, LED will Flash 1, 3

EJECT, Wait Disc Tray not moving, LED will Flash 1, 4, 1, 2

EJECT, Wait Disc Tray not moving, LED will Flash 1, 5, 1, 2

POWER OFF

Now param1 and param2 have been reset, this disables Region Patching



## Enable WIICOS and Firmware Update

POWER ON

REMOVE DVD FROM DVD TRAY

**There should be no DVD in Tray during the all sequence!**

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 2

EJECT, Wait Disc Tray not moving, LED will Flash 1, 3

POWER OFF

POWER ON, Wait DISK Tray not moving

EJECT, Wait Disc Tray not moving, LED will Flash 1, 1

EJECT, Wait Disc Tray not moving, LED will Flash 1, 2

EJECT, Wait Disc Tray not moving, LED will Flash 1, 3

EJECT, Wait Disc Tray not moving, LED will Flash 1, 4, 1, 3

POWER OFF